



PRODUCT DESIGNATION	 		
	$1 \cap T$	DESIGNATIO	N
		DESIGNATION	N

DWG. NO.

BOX CULVERT - WITH SUMPS

BC-S





<u>SUMPS</u> — WHEN LENGTH OF RUN, VELOCITY, AND AMOUNT OF SUSPENDED MATERIAL IN THE LIQUID ARE SUCH THAT SETTING WILL BE A PROBLEM, SUMPS ARE OFTEN USED. USING SUMPS, SUCH AS THE ONE SHOWN, REDUCES VELOCITY AND ALLOWS MATERIAL TO SETTLE. A MANHOLE SHOULD BE BROUGHT TO GRADE AT THE LOCATION OF EACH SUMP TO OFFER ACCESSIBILITY FOR INSPECTION AND CLEANING.